

General

The joints to be filled must be free of water, grease, dust and loose particles. Use CC Höganäs grouting mortar for clinker tiles. The mortar should be mixed according to the instructions on the package.

Grouting



1. Spread the mortar over the floor and work it into the joints with a rubber squeegee. Work the squeegee diagonally across the joints. When the joints are well filled, scrape off the excess mortar.



2. After about 10 minutes, dry mortar should be sprinkled over the surface and allowed to remain until the joints appear as a rectangular pattern. This will take about 30 minutes.



3. The surface should then be cleaned with cotton waste or a scrubbing pad. If necessary, apply additional dry mortar to ensure that the joints are well filled and the tiles are clean. Do not use sawdust. The joints should be kept moist for about 3 days. If required, use CC Höganäs FB 92 for final cleaning.